```
Código-base:
#include <XboxSeriesXControllerESP32_asukiaaa.hpp>
// Required to replace with your xbox address
// XboxSeriesXControllerESP32 asukiaaa::Core
// xboxController("44:16:22:5e:b2:d4");
// any xbox controller
XboxSeriesXControllerESP32_asukiaaa::Core xboxController;
void setup() {
 Serial.begin(115200);
 Serial.println("Starting NimBLE Client");
 xboxController.begin();
}
void loop() {
 xboxController.onLoop();
 if (xboxController.isConnected()) {
  if (xboxController.isWaitingForFirstNotification()) {
   Serial.println("waiting for first notification");
  } else {
   Serial.println("Address: " + xboxController.buildDeviceAddressStr());
   Serial.print(xboxController.xboxNotif.toString());
   unsigned long receivedAt = xboxController.getReceiveNotificationAt();
   uint16_t joystickMax = XboxControllerNotificationParser::maxJoy;
   Serial.print("joyLHori rate: ");
   Serial.println((float)xboxController.xboxNotif.joyLHori / joystickMax);
   Serial.print("joyLVert rate: ");
   Serial.println((float)xboxController.xboxNotif.joyLVert / joystickMax);
   Serial.println("battery " + String(xboxController.battery) + "%");
   Serial.println("received at " + String(receivedAt));
  }
 } else {
  Serial.println("not connected");
  if (xboxController.getCountFailedConnection() > 2) {
   ESP.restart();
  }
 Serial.println("at " + String(millis()));
 delay(500);
}
```

Código alterado com os devidos comandos:

#include <XboxSeriesXControllerESP32\_asukiaaa.hpp>

```
//====== MOTORES
int in1 = 27; // aa
int in2 = 26; // ab
int in3 = 25; // ab
int in4 = 33; // bb
// Required to replace with your xbox address
// XboxSeriesXControllerESP32_asukiaaa::Core
// xboxController("44:16:22:5e:b2:d4");
// any xbox controller
XboxSeriesXControllerESP32_asukiaaa::Core xboxController;
void setup() {
   Serial.begin(115200);
 Serial.println("Starting NimBLE Client");
 xboxController.begin();
 pinMode(in1, OUTPUT);
 pinMode(in2, OUTPUT);
 pinMode(in3, OUTPUT);
 pinMode(in4, OUTPUT);
void loop() {
 xboxController.onLoop();
 if (xboxController.isConnected()) {
  if (xboxController.isWaitingForFirstNotification()) {
   digitalWrite(2,HIGH);
   Serial.println("waiting for first notification");
  } else {
   int GD = xboxController.xboxNotif.trigRT;
   int GE = xboxController.xboxNotif.trigLT;
   int GCD = xboxController.xboxNotif.btnRB;
   int GCE = xboxController.xboxNotif.btnLB;
   Serial.println("Address: " + xboxController.buildDeviceAddressStr());
   Serial.print(xboxController.xboxNotif.toString());
```

```
unsigned long receivedAt = xboxController.getReceiveNotificationAt();
uint16_t joystickMax = XboxControllerNotificationParser::maxJoy;
Serial.print("joyLHori rate: ");
Serial.println((float)xboxController.xboxNotif.joyLHori / joystickMax);
Serial.print("joyLVert rate: ");
Serial.println((float)xboxController.xboxNotif.joyLVert / joystickMax);
Serial.println("battery " + String(xboxController.battery) + "%");
Serial.println("received at " + String(receivedAt));
// Serial.println(xboxController.xboxNotif.trigRT);
// Serial.println(xboxController.xboxNotif.trigLT);
// Serial.println(xboxController.xboxNotif.btnX);
// Serial.println(xboxController.xboxNotif.btnY);
float valorGatilho = (float) ((xboxController.xboxNotif.trigRT) * 5 )/1024;
float PWM = (valorGatilho *255 /5);
if(GD > 0 \&\& GE > 0){
digitalWrite(in1, LOW);
digitalWrite(in3, LOW);
digitalWrite(in2, HIGH);
digitalWrite(in4, HIGH);
}
 if (GD >500 && GE < 500){
   digitalWrite(in1, LOW);
digitalWrite(in3, HIGH);
digitalWrite(in2, HIGH);
digitalWrite(in4, LOW);
if (GD <500 && GE > 500){
digitalWrite(in1, HIGH);
digitalWrite(in3, LOW);
digitalWrite(in2, LOW);
digitalWrite(in4, HIGH);
if (GCD == 1 && GCE == 1 ){
 digitalWrite(in1, HIGH);
digitalWrite(in3, HIGH);
digitalWrite(in2, LOW);
digitalWrite(in4, LOW);
if (GD ==0 && GE == 0 && GCD == 0&& GCE == 0){
  digitalWrite(in1, LOW);
digitalWrite(in3, LOW);
digitalWrite(in2, LOW);
```

}

}

}

```
digitalWrite(in4, LOW);
}
} else {
    Serial.println("not connected");
        digitalWrite(2,LOW);

if (xboxController.getCountFailedConnection() > 2) {
        ESP.restart();
    }
}
Serial.println("at " + String(millis()));
}
```